
# Portable Poultry Pen



Cover	Completed Pen
Page 1	Materials List
Page 2	Assembly Instructions, Nesting Box Detail & Bar / Holder Detail
Page 3	Main Frame
Page 4	Main Frame with Roof, Roosts, Doors & Wheel / Axle
Page 5	Finished Frame & Grizzly Panels
Page 6	Wheel Assembly Detail & Door Assembly Detail
Page 7	Roofing / Grizzly Panel Attachment & Latch Detail

Materials List:

All pipe is 1" Sch 40 PVC unless otherwise noted. Quantity of pipe is approx. 163 l.f.


iten		Descriptiom	item	Qty	Descriptiom
1.	4	67" Pipe	27.	1	40"x ¾" EMT Conduit
2.	2	59" Pipe	28.	1	56"x1" Sch 80 Pipe
3.	100-200	J Clips	29.	1	1-1/4"x1" Sch 80 Pipe
4.	10	46" Pipe	30.	1	21-1/2" Pipe
5.	4	24" Pipe	31.	2	21-1/4" Pipe
6. 7	4	23" Pipe 49" Pipe	32.	1	18" Pipe
7. o	2 5	49 Pipe 40" Pipe	33.	3	13" Pipe
8. o	3		34.	2	11-1/2" Pipe
9. 10		36" Pipe	35.	2	8" Pipe
10.	2 8	18-3/4" Pipe	36.	1	6" Pipe
11. 12.	28	2-1/4" Pipe 1" Slip-T's	37.	2	54" Pipe
13.	5	1" T's	38.	1	38-1/2" Pipe
13. 14.	6		39.	2	31" Pipe
15.	3	1"90 deg. Elbow 1"45 deg. Elbow	40.	1	44" Pipe
16.	10	1" 3—way Connector	41.	1	32-1/2" Pipe
17.	6	1" 4—way Connector	42.	1	9" Pipe
18.	1	1" 90 deg. Elbow — sch 80 or	43.	1	1" Cap
10.	I	Furniture Grade	44.	2	4'x8' Grizzly Board Panels
19.	2	1" 4—way Cross	45.	2	8' x 26" or 28" wide Corrug-
20.	1	24" long Nylon Strap			ated or Flat Metal Roofing
21.	1	6'x50' Roll Chicken Wire	46.	1	Ridge Cap Metal 52" to 54"
22.	50	5" Plastic Zip Ties			long
23.	00	Self Tapping screws	47.	2	5 gal. Plastic Buckets
	50	1" @ roof & grizzly bd.	48.	2	%" x 1-1/2" Eye Bolt
	10	2" when screwing pipe to pipe	49.	1	3"x1" Pipe
24.	2	10" Pnuematic Wheels with 5%"	50.	2	6"x1" Pipe
	_	bearings	51.	1	1" Snap Clamp
25.	2	18"x√√s" Threaded Rod	52.	1	1" T- sch 80 or Furn. Grade
26.	2	8"x1/2" Sch. 40 Pipe	53.	2	5%" Nut
		- '	54.	4	% Washer
			55.	1	19-½" x ¾" EMT

### Assembly Instructions:

- 1. Assemble base and uprights as shown on page 3. Check that all Slip"T"s are in place before glueing corners and ends.
- 2. Assemble upper frame and diagonals in one operation. Check for proper fit before glueing ends and corners.
- 3. Assemble doors as shown on page 4&6 and attach to Slip "T" hinges on the main frame.
- 4. Assemble axle and wheels as shown on page 6 and attach to main frame.
- 5. Assemble Nesting Boxes as shown below , and attach to main frame as shown on page 2 with self tapping metal screws.
- 6.Attach chicken wire to main frame using "J" clips at approx. 6" o.c.. When seaming the chicken wire panels together, use "J" clips at approx. 3"-6" o.c.. When terminating the chicken wire at a pipe frame, lap the wire around the frame and use "J" clips at approx. 6" o.c..
- 7. Cut grizzly board panels out to dimensions shown on page 5. Attach Grizzly Panel Boards as shown on page 7 with self tapping metal screws at approx. 6"o.c.. Use zip ties to attach the chicken wire to the grizzly board at the bottom of Panel E.
- 8. Attach the corrugated metal roof panels as shown on page 7 using self tapping metal screws
- at approx. 6" o.c.. Be sure to use the wider 28" metal panels and overlap 2" at the center.
- 9. Install Bar & Holder assembly to outside of Panel B and screw through top and bottom into the corner pipe. see page 7


#### Nesting Box Assembly Instructions:

- 1. Take two 5 gal. plastc buckets and cut a hole in the bottoms as shown below and screw  $\frac{1}{2}$  of the lid to the top as shown below, with  $\frac{1}{2}$  self tapping screws (3 equally spaced).
- 2. Screw the two buckets together; one on top of the other with a horizontal pipe spacer between them as shown below.
- 3. Screw vertical spacers to the sides of the buckets as shown bekow.
- 4. Attach the comleted assembly to the main frame as shown on page 5.





#### Enlarged Bar & Holder Assembly Instructions:


- 1. Assemble Bar & Holder assembly as shown after Panel B is installed. See page  $5\,$
- 2. Attach assembly to upright shown on page 4&5, using self tapping metal screws one top & bottom angle the top screw on the inside of the pipe pointing downward, so it doesn't obstruct the opening.




© Copyright pvcplans.com










#### Wheel Assembly Instructions:

- 1. Install wheel assembly so item #52 item and #57 rotate freely on the item #11 rotation pins, so wheels rotate under or to the back of the poultry pen when bar #55 is used in the #29 fitting.
- 2. Place item # 52 and #57 on rotation pins.
- 3. Put axle assembly in place.
- 4. Screw through axle "T"s item #12.
- 5. Bolt wheels into place.
- 6. Items #52. & #57. may be either sch 80 of furniture grade fittings. If sch 80 is used , sand inside of fittings to allow for smooth rotation.



## Door Assembly Instructions:

- 1. Assemble door pieces as shown and attach to the slip "T"s . Slip "T"s act as hinges.
- 2. Glue Snap Clamp to vertical pipe just below the Slip "T"s.

